


How do I play a recorded file?

Note: The Homecast PVR can play its own recordings on the internal hard drive as well as photos from an external hard drive or memory card.

WARNING: Version 1.02.0A firmware will re-format an external drive if it is not already FAT32 and you will lose everything on it.

1. Switch on the Homecast PVR and wait for a picture to show on the screen. If a picture doesn't appear, your PVR may need to scan your channels first – See "How do I do a Channel Scan?"
2. Press the **LIST** button (below the **FF** button) on the remote to bring up the **File Player**.
3. Press the **◀▶ ARROW** keys to move between **File List** and **Photo Viewer** (listed on the bottom). Highlight **File List** and press **OK**
4. Press the **▲▼ ARROW** keys to move between the recordings.
5. To play a recorded file, use the **▲▼ ARROW** keys to highlight the file and press **OK**, then use the **▲▼ ARROW** keys to select **Once** or **Repeat** and press **OK** begin playing it.
6. Press **EXIT** to close the File Viewer.



7. Use the **◀▶ ARROW** keys to jump 30 seconds at a time forwards and backwards through the file.
8. Use the **PAUSE** button on the remote to pause the playback. Use the **PAUSE** button to resume viewing. **Pause** is displayed on the screen (top right hand side).
9. Press the numbered keys to jump a percentage into the file ie 3 = 30%, 9 = 90% etc...
10. Use the **STOP** button on the remote to stop playing the file.

*Note: You can also use the **FF** and **REW** and **SLOW FWD** buttons to move through the file. The **PLAY** button resumes normal play time. Repeated pressing of the **FF** and **REW** buttons will increase the play speed by x2 x3 and x4.*

11. You can view Pictures on an external HDD or USB memory stick. Connect the USB HDD or memory stick, then follow step 3, but select **Photo Viewer** (listed on the bottom) and press **OK**
12. Use the **▲▼ ARROW** keys to highlight the bold USB device and press **OK**.
13. The files on the USB device will be scanned and thumbnail pictures will appear in a window.
14. Use the **▲▼◀▶ ARROW** keys to highlight the photo you want to view and press **OK**, then either select **View**, **Slideshow** or **Exit**.

